


How Well Do LED Products Perform in the Real World? Review of tracking performance



Solid-State Lighting Market Introduction Workshop July 17, 2012

Michael Myer
Pacific Northwest National Laboratory

Today's Agenda



- Tracking performance
 - Contracts/warranty
- Issues of analysis and performance
 - Measurements
 - Lamp lumen depreciation
 - Luminaire dirt depreciation
- Economics
 - Manual measurements
 - Mobile/automated measurements
- Verification of metrics
 - Field
 - Laboratory

Tracking performance



Concern

- Sites concerned about life & cost try to mitigate it with requirements
- Contract / warranty language defining life or a certain lumen maintenance value

Example

 - "...rate not to exceed 10% from the start of operation to the conclusion of the 36 month warranty period"

Task

- Measuring lamp lumen & dirt depreciation
- Managing the data
- Paying for the costs
- Analyzing the data



Photo courtesy: Akoya

Factors for consideration



Measurement Error

- 4% output between different samples
- 2.4% difference between goniophotometer and integrating sphere
- 2% difference between laboratories

Sample Size

- More than 1 is needed
- More samples desirable / trade off with cost
- Warranty hard to enforce with a sample size of 1

Pre-installation Measurements

- Cannot rely on manufacturer data (internal QA/QC)
- Significant measurement errors could be introduced if not pre tested
- Testing, documenting, installing, and retesting of same sample at same lab is ideal

Lamp Lumen Depreciation, Initial Output?

Date		Data source	Lumens	Power	lm/W
Lum. 1	Feb. 2008	.IES file	6,462	108 W	59.8
	Sep. 2008	Data sheet	Not listed	108 W	N/A
	Oct. 2010	Data sheet	7,450	104 W	71.6
	"Clean" March 2011	Tested (.IES file)	6,044	108W	56.0
Lum. 2	May 2009	.IES file	9,912	140 W	70.8
	Oct. 2010	Data sheet	9,800 (nominal)	138 W	71.0
	"Clean" March 2011	Tested (.IES file)	5,908	82 W	72.0

Lum 1

- Claims device increases power over time for LLF > 0.95
- -6,044/6,462 = 0.935

• Lum 2

- Spot measurements found luminaire shipped with wrong driver
- Normalize input power to estimate LLD?

Lamp Lumen Depreciation, TM-21



- Value of TM-21 extrapolation
 - Industry established method of extrapolating lumen maintenance
 - Allows for a possible correlation with projections from measurements at future points in time
- Limitation of TM-21
 - Only applicable to a luminaire that operates at a constant drive current
 - Requires data to be gathered and then calculated

Lamp Lumen Depreciation, TM-21



Drive current

- Luminaires are offered at multiple drive currents
- LM-80 data is not always available at the desired drive current
- Temperature measurement point
 - TMP values not often provided on data sheets
 - LM-80 data should bookend (or be higher than) actual operating temperature of the chips

LED chips

- Not all luminaire manufacturers provide specific LED information
- Not all luminaire manufacturers link to LM-80 data of LEDs

LM-80 data

Not always easily available on chip manufacturers' websites


Lamp Lumen Depreciation, TM-21



Points:

- Green diamonds are LM-80 (20 LED samples)
- Blue triangle is @
 6,636 hours using formula
- Red square (1 luminaire sample) is calculated LLD based on measurements
- Temperature
 limitations red 38° C
 (case temp) –
 green/blue at 55° C
 (junction temp)

Extrapolated LM-80 data



Luminaire Dirt Deprecation, Is it the rain or air quality?



- Dirt depreciation
 - Longer installation, more depreciation
 - Portland, OR outlier
- Possible reasons for outlier
 - Rain in NW?
 - Luminaire construction?
 - More samples needed
- LDDs from state DOT documents
 - 0.64 to 0.95
 - Most in the mid 0.80s

Location	Installation (yrs)	LDD	
Portland, OR	2.42	0.995	
New York, NY	1.58	0.971	
New York, NY	1.58	0.960	
New York, NY	1.58	0.957	
New York, NY	1.58	0.943	
Oakland, CA	2.50	0.935	
Oakland, CA	3.42	0.889	

Luminaire Dirt Deprecation





Comparison of distributions

- Anecdotal comments that dirt affects distribution
- Figures compare "clean" & "dirty"
 luminaires
- No major differences in distribution, just reduced values for the "dirty"
- CCT no change between "clean" & "dirty"


CALIPER

- 2.4% difference between integrating sphere and goniophotometer
- Affects potential LLD comparisons / requiring both sphere and gonio





Economics How much are field measurements?



Field Measurements on FDR Drive in NYC

Photo courtesy: Ryan Pyle

Economics Manual measurements



- Equipment needs
 - Trucks for lane / road closure
 - Cones
 - Flags
- Labor needs
 - Staff for each truck
 - Staff traffic control
 - Personnel to take the measurements



Photo courtesy: Ryan Pyle

Economics How much are field measurements?




I-35W Bridge – Minneapolis, MN

Photo courtesy: BetaLED

Economics Mobile monitoring device





I-35W Bridge Field Measurements

Economics Mobile monitoring device



- Equipment needs
 - GPS with high accuracy
 - Computer
 - Multiple illuminance meters
 - Mounting hardware to truck
- Labor needs
 - Initial measurements without device
 - Runs with the truck
 - Staff members correlating and analyzing the data



PNNL

Field Measurements Advantages, challenges, issues



Advantages


- Equipment can remain in place and operating
- Capture data about the system, not just one luminaire

Challenges

- Must be repeated multiple times
- Costs each time

Issues

- Cannot separate LDD from LLD
- May require multiple field measurement sites in a large metropolis



PNNL

Economics Removing luminaires for lab testing



Equipment needs

- Replacement head once operating luminaire is removed
- Truck to remove head(s)
- Multiple luminaires needed to be removed to provide statistically significant data



Labor needs

- Limited crew to remove the luminaire
- Staff to ship the luminaire to the lab
- Management of the luminaires, both testing and operating

Other costs

Laboratory testing in both gonio and sphere

Laboratory Measurements Advantages, challenges, issues



Advantages

- Separate LLD, LDD, and other possible issues
- Provides most information about the luminaire(s)

Challenges

- Requires multiple luminaires
- Removes luminaires from service –
 limitations to long term management

Issues

- Requires multiple sets of luminaires to be tested multiple times
- Higher costs (labor, materials, testing)
- Lab-to-lab variations



PNNL

Economics How much measurements?



Activity	Type of Measurement Plan	Major Roadway	Minor Roadway	Parking Lot
Support staff (for safety)	Field & Lab	Moving lane closure \$\$\$	Flagger/spotter \$\$	As needed \$
Points marker	Field	GPS \$\$\$	Spray paint or GPS \$\$	Spray paint \$
Measurement Equipment	Field	Multiple meters \$\$	One meter \$	One meter \$
Data recording	Field	\$\$\$\$	\$	\$
Lab measurements	Lab	Sphere \$\$	Sphere \$\$	Sphere \$\$
Management of luminaires	Field & Lab	Staff time \$	Staff time \$	Staff time \$
Analysis of data	Field & Lab	Staff time \$\$	Staff time \$\$	Staff time \$\$

Recommendations



If serious:

- Financially plan for multiple luminaires tested initially in laboratories
- Do periodic spot measurements in the field
- After long-term operation, (more than 5 years) test in a laboratory

Luminaires

- Require data for TM-21 in bid
- Require QR (right) be placed on luminaire with information from the initial lab test
- QR points to database with:
 - Lumens / power input / power factor / color characteristics / critical distribution information / driver information / chip information

